## **Glencoe 1 - Instructions**

The Glencoe 1 is simplicity itself to erect.

Firstly, make sure that the inner tent and the flysheet zips are fully done up. This will keep the shape of the tent even and prevent the tent distorting when pegging out.

- 1. Lay the inner tent out on the ground.
- 2. Slide the pole sections together and carefully feed the poles diagonally through the mesh sleeves.
- Once through the mesh sleeves locate the end of the poles into the metal eyelets on the four floor corner straps. The inner tent is now free standing.
- 4. Move the inner tent to your chosen pitch and evenly peg out the four floor corner straps.
- 5. Drape the flysheet over the inner tent and clip the four corner buckles of the flysheet to the corresponding corner buckles on the inner tent floor.
- 6. Peg out the flysheet to produce a nice taut and even shape.
- 7. Attach and peg out the two guylines if required

Your tent is now erected and ready for use Any problems contact us at: station13@btinternet.com